

Belle basin & vanity installation guidelines

Supplied:

- Belle basin
- Belle vanity
- 2x vanity brackets (installed into unit)
- 6x 10x75mm coach screws
- 8x 12mm wall anchors

Installation guidelines

- Mark the placement of the vanity and make cutout for plumbing in back panel
- Drill holes for vanity brackets coach screws
- Secure the vanity to the wall using the coach screws and wall plugs supplied
- Apply silicone to the vanity and secure the vanity top accordingly
- Let silicone cure before connecting plumbing

